



Understanding our product codes



Our pads and rolls product codes explained. Take a look at this example- 1MBWRB-S

1	MB	W	R	B	-S
1 = Heavy	MB = Meltblown	W = White	R = Roll	B = Bonded	-S = Split roll
Weight 1 = Heavy (286gsm) 2 = Medium (240gsm) 3 = Single weight (165gsm)	Technology CF = Coldform™ UC = Ultraclean™ AM = Airmatrix™ MB = Meltblown	Format W = White, Oil only G = Grey, Maintenance Y = Yellow, Chemical	Product type P = Pad R = Roll	Construction B = Bonded SL = Single Lamination F = Fine Fibre L = Double Lamination	Other information -s = Split Roll -ply = Poly-backed

Our socks, booms, pillows and drum tops product codes explained. Take a look at this example- 10GS312-SB

10	G	S	312	-SB
10 = Ten	G = Grey	S = sock	3 = 3inch diameter x 12 feet long	-SB = Spun-Bond
Quantity This number identifies the numbers of products contained within the packaging	Format W = White, Oil only G = Grey, Maintenance Y = Yellow, Chemical	Product type S = Sock BOOM = Boom PILL = Pillow DRUM = Drum top	Dimensions 312 = 3 inch (8cm) diameter x 12 feet (4m) long	Other information SB = Spun-bond

Here's how our product codes work for our spill kits. Take a look at this example- SK-O05P

SK-	O	05	P	-BAT
SK- = spill kit	O = Oil only	05 = 5 US Gallons	P = Pail	-BAT = Battery acid
Kit description SK = Spill kit DASH = spill kit in a dash bin	Format O = Oil only U = Universal or Maintenance Y = Yellow, Chemical	Spill kit size the figure indicates the size of spill the kit can recover	Other information P = Pail TB = Zipper bag ZB = Clear Zipper bag TBV = Vinyl velcro bag	Special Kits BAT = Battery acid spill kit

For help in selecting a product call 905.670.5401 or visit www.espsorbents.com/ca